MoFi 6500 Captive Portal

Complete Administrator Guide & Documentation

Version 4.0.5 | September 25, 2025

Overview

What is the MoFi Captive Portal?
A guest network management system that controls WiFi access by requiring users to view a splash page before accessing the internet.

Session Control
Limit guests by time, data usage, or bandwidth speed. Automatically disconnect expired sessions.

Guest Authentication
Require guests to accept terms, enter passwords, or verify email addresses before accessing the internet.

Access Planning
Control how many guests can connect and how much bandwidth remaining services.

Live Statistics
Monitor who's connected and connected information.

Easy Management
Create vouchers, manage configuration with clear explanations.

Mobile Ready
Optimized for smartphones and tablets.

System Components

- **Captive Portal Engine:** Core authentication system
- **Splash Page Server:** Displays customizable login screens
- **Traffic Shaper:** Controls bandwidth limits
- **Session Tracker:** Monitors active guest sessions

Quick Start Guide

Get your captive portal running in 5 minutes!

Step 1: Access Router Admin

```
http://192.168.10.1 Username: root Password: admin
```

Step 2: Navigate to Captive Portal

Go to **Services** → **Captive Portal**

Click **Add** to create a new zone

Configuration: Start settings and ACL rules

MACs: Manage allowed devices

Vouchers: Generate and manage vouchers

Step 3: Basic Configuration

1. Check **Enable Captive Portal**
2. Select WiFi interfaces (default: guest networks)
3. Set **Authentication Mode** to **None**
4. Set **Redirection URL** to `http://portal.mofi.network`
5. Click **Save & Apply**

Step 4: Test the System

1. Connect a device to the guest WiFi
2. Open a web browser and visit any website
3. Verify splash page appears
4. Click **Accept** to authenticate
5. Confirm internet access works

Important: Enabling captive portal disables hardware NAT acceleration. Apply only to guest networks for best performance.

Configuration Options

Complete GUI Coverage: This documentation covers ALL 30 configuration options available in the MoFi Captive Portal GUI interface.

Basic Settings

Setting	Description	Default	Recommendations
Enable Captive Portal	Master on/off switch	Disabled	Enable for guest networks only
MAC Interfaces	Select which interfaces use portal (Multi select)	default_wireless, default_ethernet	Use multiple, pointing for specific only
Block High Bandwidth Websites	Enable streaming services filtering	Disabled	Enable for public WiFi to preserve bandwidth
Block Out Access from Captive Portal	Prevent portal users from accessing router admin	Disabled	Enable for security, otherwise http://192.168.10.1:1000
Gateway Name	Name shown to users (used as "Host")	"MoFi Captive Portal"	Use your business/location name
Maximum Clients	Concurrent user limit	250	Set based on bandwidth capacity and router performance

Timeout Settings

Setting	Description	Default	Use Case
Hard Idle Timeout	Minutes before users come back	1440 min (24 hrs)	60 min for high-turnover guest areas
Session Timeout	Maximum session length	1440 min (24 hrs)	480 min (8 hrs) for daily access

Advanced Settings

Setting	Description	Default	Use Cases
Debug Level	Verbosity of logging (0-3). Higher = more detail	1	Set to 2-3 for troubleshooting issues
Log all client authentication events	Log all client authentication events	Disabled	Enable for monitoring and compliance
Redirect URL	URL to redirect users after authentication	Empty (stay on current page)	Example: http://www.mofinetwork.com
Portal Password	Password required for access (empty = no challenge)	Empty	Use "system" for admin bypass, custom for guests

Security Options

Portal Password
Purpose: Client-to-server auth
Use Cases: Supported by clients
Format: Use "system" for admin bypass

Block Bad Devices
Prevents portal users from accessing suspicious router
Alternative: http://192.168.0.1:1000

Webpage Warning
Title: Page bandwidth advertising services
Configure in "Website Block List" tab

Access Control Lists (ACL Rules)

Important: Rules are checked in order. Use specific rules to allow traffic before general rules. Always place DENY rules after more permissive rules.

- **Key Concept:** ACL rules are stateless network traffic paths
- **Rule Direction:** Controls traffic from client to router (not client to internet)
- **Router Access:** Controls traffic to router (192.168.10.1)
- **Best Practice:** Controls traffic to/from splash page configuration

1. Authenticated Users

When Applied: Users who have valid, THROUGH the router after completing captive portal
Traffic Flow: Client → Router → Internet (forwarded traffic)

```
iptables -I FORWARD -i br-guest -m mac --mac-source AA:BB:CC:DD:EE:FF -j ACCEPT
iptables -I FORWARD -i br-guest -m mac --mac-source 11:22:33:44:55:66 -j ACCEPT
```

Result: Users can browse internet but cannot access other network services. Router access (192.168.10.1) is controlled by separate Router Access rules.

2. Pre-Authenticated Users

When Applied: Users connected to WiFi but NOT YET authenticated via captive portal

```
iptables -I FORWARD -i br-guest -d 192.168.10.1 -p tcp --dport 80 -j ACCEPT
iptables -I FORWARD -i br-guest -d 192.168.10.1 -p tcp --dport 443 -j ACCEPT
```

Purpose: Allow clients to access captive portal page (splash.html) and get redirected to the captive portal, but they can't actually browse anything.

3. Router Access Users

When Applied: Client device TCP-like his/her admin interface (192.168.10.1)
Traffic Flow: Client → Router (input traffic)
Key Point: These rules control authenticated users and apply when visiting 192.168.10.1

```
iptables -I INPUT -i br-guest -m mac --mac-source AA:BB:CC:DD:EE:FF -j ACCEPT
iptables -I INPUT -i br-guest -m mac --mac-source 11:22:33:44:55:66 -j ACCEPT
```

Why Separate Rules: This is why you can access 192.168.10.1 admin even with "block to 192.168.0.0/16" in Authenticated Users - they control different traffic paths (FORWARD vs INPUT).

Rule Format Examples

Rule	Meaning	Use Case
`ACCEPT -i br-guest -m mac --mac-source AA:BB:CC:DD:EE:FF`	Allow HTTP/HTTPS access	Authenticated users
`DROP -i br-guest -d 192.168.0.0/16`	Allow HTTPS secure browsing	Secure websites
`DROP -i br-guest -d 192.168.10.0/24`	Block access to main LAN	Prevent access
`ACCEPT -i br-guest -d 192.168.10.1 -p tcp --dport 80`	Allow DNS (necessary)	Name resolution

Common Port Numbers

Web Services

- **Port 80:** HTTP (websites)
- **Port 443:** HTTPS (secure websites)
- **Port 8080:** Alternate HTTP

Network Services

- **Port 53:** DNS (name resolution)
- **Port 67:** DHCP (IP assignment)
- **Port 123:** NTP (time sync)

Admin Services

- **Port 22:** SSH (secure shell)
- **Port 80:** Telnet (insecure shell)
- **Port 1000:** Router management

MAC Address Control

Control which devices can access the captive portal based on their hardware MAC address.

Setting	Description	Format	Use Case
MAC Address Control	Choose "Allow" (whitelist) or "Block" (blacklist) mode	Dropdown selection	Security/access control policy
Allowed MAC Addresses	Only these devices can use captive portal (whitelist mode)	aa:bb:cc:dd:ee:ff	Restricted access environments
Blocked MAC Addresses	These devices are denied captive portal access (blacklist mode)	aa:bb:cc:dd:ee:ff	Ban problematic devices
Trusted MAC Addresses	These devices bypass captive portal entirely (immediate internet access)	aa:bb:cc:dd:ee:ff	Staff devices, IoT devices, printers

MAC Address Format: Use colon-separated format like `aa:bb:cc:dd:ee:ff`. Not case-sensitive. MAC addresses are found in DHCP client list or device settings.

Complete GUI Options Summary

Tab	Total Options	Key Settings
Configuration	18 options	Enable Portal, MAC Interfaces, Block Websites, Block Out, Gateway Name, Max Clients, Timeouts, Session Timeout, Debug Level, Logging, Redirect URL, Password, Auth Level (ACL), Pre-Auth Users (ACL), Router Users (ACL), MAC Control, Allowed MACs, Blocked MACs, Trusted MACs
Splash Page Editor	1 option	Splash Page HTML Content (full HTML editor with template variables)
Website Block List	1 option	Blocked Domains List (domain names, one per line)

Authentication Modes

Mode 1: Click-to-Continue (No Password)

Configuration

Leave "Portal Password" field **empty**

User Experience

1. Connect to WiFi network
2. Open any browser
3. See splash page with "Accept & Continue" button
4. Click button to get internet access

Pros & Cons

- ✓ Public spaces, cafes, libraries
- ✓ High traffic, quick rotations
- ✓ Minimal friction requirements

Mode 2: Password Authentication

Configuration

Enter password in "Portal Password" field

User Experience

1. Connect to WiFi network
2. Open any browser
3. See splash page with password form
4. Enter the shared password
5. Click "Continue to Internet"

Pros & Cons

- ✓ Business guest networks
- ✓ Controlled access environments
- ✓ Temporary access codes

Special Passwords

Password	Effect	Session Timeout	Use Case
`system`	Unlimited access	No timeout	Administrator bypass
Custom password	Normal access	Configured timeout	Guest users

Splash Page Customization

Available Templates

Legend: Mode

Mode: Click-to-continue
Features: Modern design, terms & conditions, user statistics

Legend: _classic.html

Mode: Password authentication
Features: Password form, security focus, professional layout

Current Design Features

- ✓ **SVG Modern Styling:** Gradients, rounded corners, shadows
- ✓ **Mobile Responsive:** Adapts to all screen sizes
- ✓ **Live Statistics:** Shows current user count
- ✓ **Terms & Conditions:** Collapsible legal text
- ✓ **Connection Info:** Gateway, DNS, session timeout

Customization Options

Access: Go to "Splash Page Editor" tab in captive portal configuration

Full HTML Editing
Complete control over layout and styling

Template Variables
Dynamic content insertion

Visual Support
Live preview of changes

- Syntax highlighting editor
- Real-time preview
- Line-by-line numbers
- Automatic updates
- Professional appearance
- Background images
- Brand colors

Template Variables

Template variables are dynamic placeholders that get replaced with live data when users see the splash page.

Basic Variables

Variable	Description	Example Output
`{{gatewayname}}`	Gateway name from config	"MoFi Captive Network"
`{{clientip}}`	Client's IP address	"192.168.10.1:2000/splash?redirect=aHR0"
`{{clientmac}}`	Password form action URL	"http://192.168.10.1:2000/auth"
`{{redirect}}`	Hidden redirection field	"hidden"

Client Information

Variable	Description	Example Output
`{{clientip}}`	Client's IP address	"192.168.1.100"
`{{clientmac}}`	Client's MAC address	"aa:bb:cc:dd:ee:ff"
`{{redirect}}`	Original URL client was trying to access	"http://example.com"

Gateway Statistics

Variable	Description	Example Output
`{{uptime}}`	Current connected users	"12"
`{{maxclients}}`	Maximum allowed users	"100"
`{{sessionTimeout}}`	Router uptime	"1 days, 14:32:05"

Usage Examples

```
<h1>Welcome to {{gatewayname}}</h1>
<p>Your IP: {{clientip}}</p>
<p>Your MAC: {{clientmac}}</p>
<p>Session timeout: {{sessionTimeout}} minutes</p>
<p>Current users: {{uptime}} / {{maxclients}}</p>
<form action="{{authaction}}" method="post">
<input type="hidden" name="redirect" value="{{redirect}}">
<input type="hidden" name="clientip" value="{{clientip}}">
<input type="hidden" name="clientmac" value="{{clientmac}}">
<input type="password" name="password" placeholder="Enter password">
<button type="submit">Connect</button>
</form>
```

Current Implementation: The MoFi splash pages use Bandwidth Monitor to show live user count and bandwidth to display. Unfortunately this is the only variable.

Website Blocking

How Website Blocking Works

It loads "Block High Bandwidth Websites" in main configuration

1. Configure blocked domains in "Website Block List" tab
2. Enable "Block High Bandwidth Websites" in main config
3. Changes take effect immediately (no restart required)

Default Blocked Services

Video Streaming

- Netflix (netflix.com)
- YouTube (youtube.com, youtu.be)
- Hulu (hulu.com)
- Disney+ (disneyplus.com)
- Amazon Prime Video

Live Streaming

- Twitch (twitch.tv)
- Facebook Live
- Periscope
- TikTok videos

Gaming Platforms

- Steam (steampowered.com)
- Epic Games (epicgames.com)
- Xbox Live (xbox.com)
- Twitch videos

Adding Custom Blocks

```
# Example: Block gym class's video conference website and other distracting sites
# Add these domains to the "Website Block List" tab:
zoom.us
meet.google.com
discord.com
```

Performance Note: Website blocking adds minimal overhead but examines Web (DNS + Bandwidth) may impact performance on high-traffic networks.

Troubleshooting

Common Issues & Solutions

Captive Portal Not Appearing

Symptoms: Device connects to WiFi but don't see splash page

Solutions:

1. Verify "Enable Captive Portal" is checked
2. Check that WiFi interface is in MAC Interfaces
3. Try with different device or incognito browser
4. Check service status: `ps | grep -E "dnsmasq|uhttpd|nodogsplash"`
5. Restart service: `/etc/init.d/dnsmasq restart && /etc/init.d/uhttpd restart`

Password Authentication Failing

Symptoms: Correct password is rejected

Solutions:

1. Check for extra spaces in password
2. Avoid complex special characters
3. Clear browser cache or use incognito mode
4. Verify password is saved correctly in config

No Internet After Authentication

Symptoms: Splash page works but no internet access

Solutions:

1. Check DNS is set for authenticated users
2. Ensure ports 80 and 443 are allowed
3. Verify DNS rules in pre-authenticated users
4. Test outside local connectivity

High CPU Usage / Slow Performance

Symptoms: Router becomes slow or unresponsive

Solutions:

1. Reduce maximum clients setting
2. Implement shorter session timeouts
3. Optimize website block list
4. Check nodogsplash and firewall rules

Log File Locations

Log Type	Location	Contents
Captive Portal	`/tmp/log/nds.log`	Authentication events, client connections
System	`/tmp/log/messages`	General system events and errors
Authentication	`/tmp/log/auth.log`	Password authentication attempts

Debug Commands

```
# Check service status and restart if needed
ps | grep -E "dnsmasq|uhttpd|nodogsplash"
/etc/init.d/dnsmasq restart && /etc/init.d/uhttpd restart
# Monitor captive portal logs in real-time
tail -f /tmp/log/nds.log
# Check firewall rules for captive portal
iptables -L -n | grep -E "nodog|captive"
# Test DNS resolution
nslookup google.com 192.168.10.1
```

Best Practices

Security Recommendations

Password Management

- Change passwords regularly (monthly)
- Use strong, unique passwords
- Document password changes for staff
- Use "system" password for admin devices

Network Isolation

- Block private networks (192.168.x.x, 10.x.x.x)
- Limit guest access to internet only
- Use MAC filtering for sensitive areas
- Monitor connected devices regularly

Access Control

- Use appropriate timeout settings
- Implement bandwidth limits per user
- Implement fair usage policies
- Regular security audits of ACL rules

Performance Optimization

Client Management

- Set realistic maximum client limits
- Use shorter timeouts for high-traffic areas
- Monitor concurrent user patterns
- Adjust limits based on usage data

Bandwidth Usage

- Apply to guests networks only
- Block streaming services if needed
- Optimize splash page for mobile devices
- Schedule maintenance during low usage

User Experience

Splash Page Design

- Keep authentication process simple
- Ensure mobile-first design
- Test on various devices
- Maintain professional appearance

Terms & Conditions

- Use clear, understandable language
- Keep policies reasonable and fair
- Update regularly as needed
- Ensure local law compliance

Maintenance Schedule

Frequency	Tasks	Time Required
Daily	Monitor user count, check alerts, verify connectivity	5 minutes
Weekly	Review logs, update block lists, check performance	15 minutes
Monthly	Change passwords, update terms, backup config, security audit	30 minutes
Quarterly	Full system review, firmware updates, performance optimization	1-2 hours

Recommended Settings by Environment

Environment	Max Clients	Session Timeout	Hard Timeout	Website Blocking
Coffee Shop	Close to continue	120 minutes	60 min	Enable streaming
Hotel	Hotel + airline password	24 hours	480 min	Selective
Office Guest	Daily password	8 hours	30-60	Enable (social media)
Library	Close to continue	240 minutes	180 min	Enable (gaming/streaming)

Support & Resources

Documentation
Repository: Add firmware-docs/MoFi6500
Latest: 2025.09.25
Files: MoFi_Captive_Portal_Complete_Guide.txt, MoFi_Captive_Portal_Complete_Guide.html
Version: 4.0.5 | September 25, 2025

Configuration Files
Main Config: /etc/config/nodogsplash
Splash Page: /etc/nodogsplash/htdocs/splash.html
Website Block List: /etc/config/nodogsplash_blocklist
Templates: /etc/nodogsplash/htdocs/

Service Control
Restart Service: /etc/init.d/nodogsplash restart
Check Status: ps | grep nodogsplash
Logs: /tmp/log/nds.log

Latest Updates (2025.9): Modern splash page design, enhanced template variables, comprehensive ACL explanations, live statistics display, improved mode documentation.

© 2025 MoFi Network Inc.
This documentation is provided for MoFi 6500 router administrators.
Generated on September 25, 2025 | Version 4.0.5